



A1	B1	A2	B2	
0	0	0	0	All Off
0	1	0	0	TX Only
0	1	1	0	TX Only
0	1	0	1	Full Duplex TX and RX
0	0	0	1	RX from secondary RX port
1	0	0	1	RX from secondary RX port
1	0	1	0	RX from primary TX/RX port
0	0	1	0	Nothing
1	0	0	0	Nothing
0	0	1	1	BAD!
0	1	1	1	BAD!
1	0	1	1	BAD!
1	1	0	0	BAD!
1	1	0	1	BAD!
1	1	1	0	BAD!
1	1	1	1	BAD!



Always On



Band	Upconverter	Downconverter	Upconverter VCO	Downconverter VCO
400 – 500 MHz	AD8345	AD8348	ADF4360-7 (Div by 2)	ADF4360-3 (Div by 2)
800 – 975 MHz	AD8349	AD8347	ADF4360-3 (Div by 2)	Same
1.2 – 1.3 GHz	AD8349	AD8347	ADF4360-0 (Div by 2)	Same
2.3 – 2.4 GHz	AD8349	AD8347	ADF4360-1	Same
2.4 – 2.7 GHz	AD8349	AD8347	ADF4360-0	Same

Flex2400 Common	
TITLE	\$Date: 2006/03/10 02:20:13 \$
FILE:	\$Source: /opt/usrp-hw-cvs/usrp-hw/flex_xcvr/common/flex2400.sch,v \$Revision: 1.2 \$
PAGE	1 OF 3
DRAWN BY:	\$Author: matt \$

