



900-2600 MHz PCB Log Periodic WA5VJB



Notes: Coax should be routed along the "Boom" or at 90 deg to the antenna.

Mounting holes can be drilled through the Fiberglass between elements near the back of of the antenna.


Typical Antenna Factors

MHz			
900	26.3	1800	29.3
1000	24.2	2000	30.2
1200	35.8	2450	32.0
1500	27.7	2600	32.4

Title			PCB-LP Antenna
Size	Number	Rev	
B	NTMS	A	
Date: 5-2-03		Drawn by: KEB	
File Name: PCBLPSMA.pcb		Sheet 1 of 1	

CH1: A -M - 19.19 dB
5.0 dB/ REF - .00 dB

Return Loss / SWR Plot



900-2600 MHz SAA L-Band LP